User Manual

TVIX™ HD café.

**** Some specifications could change with new firmware versions. Please refer to the FAQ on our homepage for further information**

Safety Notice



Do not try to disassemble or remodel the unit. Doing so may cause malfunction or fire.



Place all magnetized devices, such as speakers, away from the unit .It may erase or cause damage to the data stored in the hard disk.



Do not place the unit in places that are exposed to oil, water, dust, humidity, rain or wind.



Keep your unit away from heated areas, such as direct sunlight exposure, heaters and etc. Place it in a well ventilated location. Ensure that a free airflow is maintained around the appliance.



Do not touch the power plug with wet hands or use defective power cables & electric outlets. It may cause electric shocks or fire.

Do not drop the unit from heights. Doing so may cause critical damage to the hard drive.

The socket-outlet shall be installed near the equipment and shall be easily accessible.
Unplug the power cable when you are not using the product for a long time.

Table of Contents

Safety Notice 2

1 Introduction 4
1.1 Multimedia Player Function 4
1.2 Specifications 5

2 Name of Each Part 6
2.1 Unit Control button 6
2.2 Cable Connection 6
2.3 Package Contents 7

3 Installation and Connection 8
3.1 Connecting the Video 8
3.2 Connecting the Audio 9
3.3 Connecting the USB HOST 10
3.4 Using the remote control 11
3.5 Initial Setting 12

4 Setup Menu 13
4.1 SYSTEM Setting 13
4.2 Audio/Video Setting 15
4.3 NETWORK Setting 17
4.4 MISC Setting 19

5 Initial Usage 20
5.1 Movie Playback 20
5.2 Music Playback 21
5.3 Photo Playback 22

6 Using the remote control 23
6.1 Descriptions of Each Button 23
6.2 Extra Features 29

7 Using Network 35
7.1 Using UPnP 35
7.2 Using NetShare 42
7.3 Using SAMBA Client 47

8 Firmware Upgrade 54

9 Using USB Connection with a PC 55
9.1 Making a Partition and Formatting the HDDs 55
9.2 Unplug or Eject Hardware 58

10 Troubleshooting 59

11 Appendix - Technical Terms 60

12 GNU General Public License 62

1 Introduction

1.1 Multimedia Player Function

The TVX-HD is a standalone, multimedia player that plays digital videos, digital music, digital still images and DVD files on TV screens and home entertainment systems. You can enjoy digital contents in your living room without having to burn discs or to play it back on a DVD or CD player anymore.

TVX-HD plays back DVD movies with the full functionality of DVD navigation. You can create your own virtual DVD library by storing your personal collection of DVDs in .ISO or .IFO format, and watch them exactly as if they were running from the original DVDs (all the original features are included: Menu, Chapter, Audio Stream, Subtitle, Fast Forward, Rewind, Pause, Repeat, Search etc.).

TVX-HD can play high-definition videos (up to 1920x1080P) and still images. Pre-recorded HDTV programs from a digital TV set-top box or personal digital video contents recorded by a camcorder can be played back with the TVX-HD on a high-definition screen. The TVX-HD features an HDMI connector, which will match the high resolution of HD-level video contents.

TVX-HD supports the latest multimedia formats such as MKV, MPEG-4 AVC(H.264), VC-1(MP@HL, AP@L3), WMV9 & WMV HD as well as MPEG4 3.11,4.0 , 5.0. and H.264, which is a brand-new and superb compression technology. It can now play more stunning HD movies with lower storage requirements.

HDMI provides unparalleled qualities to digital videos and audios, while DVI only serves digital videos. With HDMI you don't have to deal with multiple AV cables. It lets you make a connection to digital videos as well as audios, and enjoy them with just one cable. It can deliver uncompressed digital video up to 1080P as well as digital audio.

TVX-HD has a DTS hardware decoder to mix DTS sound into 2 channels for a more dynamic stereo sound quality.

The TVX-HD can be networked with a PC system using either a wired network or its optional wireless network adapter. You can navigate to a PC file through TVX-HD's wired/wireless network and play the file from its original location without having to copy it into the TVX-HD first. Also, FTP server allows you to transfer files from your PC. It also allows you to connect to network easily with uPnP support, and it does not require an IP address. You can immediately playback uPnP connected files.

With two USB2.0 host ports, you can attach additional external USB hard drives to further extend the storage capacity. You can also play back files from a digital cameras, USB flash drives, USB flash card reader or an MP3 player.

Manufactured under license from Dolby Laboratories.

"Dolby" and the double-D symbol are trademarks of Dolby Laboratories.

1.2 Specifications

MODEL	TVX-HD N1
Main Chipset	RTD1073DD 400Mhz processor
Video	Format: .MKV, .mpg, .avi, .wmv, .divx, .vob, .tp, .ts, .trp, .dat, .iso, .ifo, .m2t, .m2ts, .mov, .flv
	Codec: MPEG 1/2/4, AVI, XVID,WMV9(MP@HL),H.264(MP@HL4.1),VC-1(AP@L3), RealVideo 8/9/10
	Resolutions up to 1920*1080P
Audio	FLAC, DTS-Wav, MP3, WMA, WMA Pro, AAC, Ogg, Dolby Digital, WAV
	DTS Pass Through and Down Mixing
Photo	JPG, JPEG (Progressive JPEG not Support), BMP, PNG, GIF, TIF
Connectivity	USB 2.0 Host 3 Ports (USB1/USB2 : 5V⎓, 500 mA max)
	Wired LAN, optional wireless LAN
	Network : Samba client, NFS, Netshare, FTP, Upnp
	Memory Card reader : SD, SDHC, Memory Stick, Memory Stick Pro Duo
Video out	HDMI 1.3, Component, Composite
Audio out	Digital : Optical , Analog: Stereo
Hard Disk	NTFS, FAT32
Subtitle	smi, smil, sub, sub/idx, srt, .ssa, .ass
Memory	128M byte
Power	DC 5V adaptor
Language	English, Traditional Chinese, Japanese, Spanish, French, Germany, Italian, Korean, Dutch, Russian, Rumanian, Bulgarian, Hebrew, Czech, Vietnamese
Size	Cylindrical, 109mm * 144mm (W x H)

2 Name of Each Part

2.1 Unit Control button

To use memory card reader or power button, open the top cover case.



2.2 Cable Connection

You can connect the TVX-HD to a TV display or audio amplifier using the A/V cable.



2.3 Package Contents

Thank you for choosing this product.

The package contains the following items. The items described below may differ from the actual contents.



Main unit

Remote Control



RCA Cable

Quick Guide



Manual CD



Power Adaptor

** Connect the included power cable on the back of the TVX-HD. Then plug the other end of the power adapter into an available wall socket. Make sure that your TV is switched to the AV input to which the TVX-HD is connected (on the back of the TV).

<< Before Connecting the Cable >>

1. Please refer to TV manual for the connection of A/V cable.
2. Make sure the power is off when you are connecting the A/V cable between the TVX-HD and the TV.
3. Connect the red and white RCA cable for stereo audio.

3 Installation and Connection

3.1 Connecting the Video

The TVX-HD supports HDMI , Component and Composite video output for connection to a TV, and each output needs to be selected in the settings menu depending on what cable is being used.

Connection to Composite	Connection to HDMI Output





Connect the TVX-HD output to your TV using the included Composite (yellow) video cable.
Select the appropriate video input mode on your TV until you get the main page of the TVX-HD.
For the Audio, please connect the stereo cable (red/White cable).

Connect the TVX-HD output to your TV using an HDMI cable.
TVX-HD plays back high definition videos (up to 1920x1080P) by using HDMI cables.
HDMI cable can transmit uncompressed audio and video signals together at the same time. No additional cables are needed.

Connection to Component Output :

Connect the product and your TV using the component cables.
Turn on the product and the TV. Select an appropriate video output mode on your TV until you get the main page of the product. Additional cables required for the audio.

3.2 Connecting the Audio

Connection to 2 CH Normal TV



Connect the two audio cables, the white one on the left side and the red one on the right side, to the appropriate terminals of your TV or Hi - Fi system for sound output.

Connection to 5.1CH Amplifier (Digital)



If you have a multi-channel decoder/amplifier with an optical input, you can enjoy 5.1 CH high- quality sound through the optical cables.
The illustration above shows how to connect the optical cable with an included optical jack.
(These cables are not included in the package and must be purchased separately.)

NOTE

After you connect the video cable to your TV, you must press the TV Out button on your remote repeatedly control until you see the main page of the TVX-HD on the screen.

If there is still no sound after connecting the Optical cable, you have to change the audio setup of TVX-HD to Digital on the SETUP menu.

3.3 Connecting the USB HOST

The TVX-HD also provides two USB-host ports with USB 2.0 compliant host/ function processor.



USB-host allows communication between 3 USB devices. You can connect any external storage device (e.g. memory stick) or any external hard disk to play files stored in these external devices. You can even connect your Digital Camera directly to play digital images and pictures without any other devices.

After connecting the client device, press the GOTO button on your remote control, and then navigate to the desired storage unit. You can thereby change the location from external USB device to network device and back.



3.4 Using the remote control

This indicates Remote control Buttons.

POWER		Toggle Unit Power on / off
MUTE		Stop Audio Output from the Player
MOVIE		Go to Movie folder
MUSIC		Go to Music folder
PHOTO		Go to Photo folder
SETUP		Enter Setup Menu, Apply/Confirm Setup Settings
Numeric Key	7	Insert number
16:9/4:3		Aspect ratio(16:9/4:3 letter box/4:3 Pan&Scan)
ZOOM		Zoom Video / Image Playback
PREV		Previous Chapter / File / Page Up on List
Next		Next Chapter / File / Page Down on List
JUMP/REW	Jump	Jump to USB Host or network drive
SORT/FF	Sort	File Sort or FF playback
OK		Selection/play/pause
ARROW		Cursor Navigation Arrow/Rewind / FF playback
RETURN		Stop Playback/Return to Previous Screen / Folder
VOL + / -		Volume (Increase / Decrease)
CH + / -		Adjust subtitle sync
INFO		Display Media File Information
SUBTITLE		Subtitle ON / OFF, Change Settings
BOOKMARK		Bookmark
GOTO		Time-Stamp based Search/Switch Device
ADD/DELETE		Delete file or folder
AUDIO		Select multi audio
REPEAT		Repeat Media file(s) Playback
SHUFFLE		Switch between Random – Sequential Playback
TV OUT		Toggle Video Output Modes
TITLE		Goto DVD title menu
MENU		Display Main Menu Screen/ DVD Menu Screen
FUNCTION		File copy/ folder password/ Sleep Timer

3.5 Initial Setting

1 Connect the TVX-HD to your TV using A/V cables, and turn on the TVX-HD. You will see the following screens when you turn the unit on for the first time or when you select “Load Default Setting”.

2 When you see the initial page on your TV screen shown in the picture below, press the “OK” button on the remote control.

- In case of HDMI connection: TVX-HD does not show this page but sets to the best resolution automatically and leads you to the next stage, “Language setting”.
- In case of other connections: TVX-HD changes screen resolutions between NTSC, PAL, 480P, and 576P about every three seconds until the “OK” button is pressed, so press the “OK” button when you can see a clear screen.

3 Select the language.

4 Now you can see the TVX-HD main page.

4 Setup Menu

4.1 SYSTEM Setting

This section is about SYSTEM (Language or List Type) settings. Press SETUP button on the remote control and select SYSTEM.

This screen allows you to adjust the SYSTEM settings of your TVX-HD to your personal taste. Select menu to exit this SETUP. Press 'NEXT' button to move on to the next setup.



Menu Language : Select your language.

File List Type : Select File list type.

List mode

Preview mode



Cover Art

Auto Run : You can make files play automatically when TVX-HD gets loaded. If you select “random”, they play in a random order.

Set Screen Position : Adjust the UI display position, so that you can see the main UI display at the right place on your TV.
Arrow buttons and OK button are available.

1. Adjust Left - Top blue line.
2. Adjust Right - Bottom blue line.

Automatic F/W Update : Now you can upgrade a new firmware if your TVX-HD is connected to the internet. To upgrade it with our beta version of firmware, please press 2,3,8,2 of the numeric keys and then press the ‘Function’.

Load Default Settings : In order to revert to the Default setting, select this option. You will need to configure the video and sound settings again.

4.2 Audio/Video Setting

This section is about A/V (Video or Audio) settings. Press SETUP button on the remote control and select the A/V.

This screen allows you to adjust the A/V settings of your TVX-HD to your personal taste. Select menu to exit this SETUP. Press 'NEXT' button to move on to another setting.

Set the **audio output** setting.

Select the HDMI or the S/PDIF (CUSTOM) that you want to hear the audio.

If you select the S/PDIF, you can set the detailed audio output with your Decoder/Amplifier. We recommend you to set the Dolby Digital and DTS to digital and AAC to analog.

You don't need change this option when you connect RCA cable.

Digital Audio output (Digital RAW) : Select this when you connect the audio with an coaxial/optical cable for digital audio connection to the Decoder/Amplifier.

Dynamic Range Control : This function is for either decreasing high level sounds or increasing low level sounds.
[ON]: low volume at late night.
[OFF]: full dynamic range of the volume.

Video Output : Select this when you want to connect the video through a composite or a HDMI cable. With HDMI setting, you can select an output resolution between NTSC,PAL, 720p 50hz/60hz, 1080i 50hz/60hz and 1080P. 1080i should work on all HD grade TVs.

Aspect Ratio : 4:3 Letter Box / 4:3 Pan & Scan for ordinary TVs; 16:9 for Wide TVs, such as HDTV or Plasma TV.

If the ratio of the TV is 4:3, select the 4:3 letter box or 4:3 Pan & Scan. If the ratio is 16:9, select 16:9.

* The 4:3 Letter box can show the original ratio of the multimedia file in 16:9.

* The 4:3 Pan & Scan will adjust the image of the 16:9 multimedia file to the 4:3 of the TV screen by scaling the image. (This mode is currently not supported)

* 16:9 can adjust any ratio of the multimedia file to the TV screen with the original image.

Video Adjust : Set the Brightness - Contrast - Hue - Saturation.

Press OK or STOP button to save and exit current video setting.

Video Auto Switch : is used when the video out is changed according to the 1080P 24Hz format.

Apply Video Output : press 'Apply Video output' to save current Video output mode.

4.3 NETWORK Setting

This section is about NETWORK (Network or FTP) settings. Press the SETUP button on the remote control, and then select NETWORK.

This screen allows you to adjust the NETWORK settings of your TVX-HD to your personal taste. Select menu to exit this SETUP. Press 'NEXT' button to move on to the next setting.



**** For detailed Network instructions, please refer to the enclosed TVX-HD CD or the latest pdf file on the TVX-HD Homepage.**

It allows you to connect to network easily with uPnP support, and it does not require an IP address. You can immediately playback uPnP connected files (even full HD files) on wired/wireless network environment.

With NFS, TVX-HD can play high bit-rate files from a PC flawlessly over a LAN.
We recommend NFS connection over SAMBA. You need to install the TVX-HD Netshare program (or other NFS server) on the server PC, but the settings are much easier than in SAMBA mode.
You can download NetShare installer from our website to easily configure your NFS network.

Default Network Type : Select Wired network or Wireless network.

Wired IP Setting: Default setting is Auto(DHCP). If you cannot access via LAN with DHCP setting, use the Static IP setting. For a static IP, refer to the **LAN Connection**.

Wi-Fi IP Setting : Default setting is Auto(DHCP). If you cannot access via LAN with DHCP setting, use the Static IP setting. For a static IP, refer to the **LAN Connection.**

Search Wi-Fi Network : Connect the USB module to TVX-HD after connecting the AP Router to a PC. Press "Search Wi-Fi Network" to search for your AP or AP router. Spend some time searching for it, and you will see the AP LIST popup menu. Select the AP that you want to connect to.





Setup Network Disk : This function searches and helps you find PCs connected to the network.
SAMBA: If you have a guest account, shared folder names can be listed and can be selected.
NFS: Connected PCs are listed automatically in NFS of NAS storage or Netshare.
In case of Netshare, if you select a tvixhd1 or tvixhd2, IP of PC is displayed.



TVX-HD Network Info : You can see the information of TVX-HD's Network.



FTP ID/PW : to use FTP function, you must use the ID & password displayed on the Network in Menu within SETUP. The FTP ID is tvixftp. You can use capital letters only for the password.

4.4 MISC Setting

This section is about MISC (Photo effect and Subtitle) settings. Press the SETUP button on the remote control, and then select MISC.

This screen allows you to adjust the MISC settings of your TVX-HD to your personal taste. Select menu to exit this SETUP. Press 'NEXT' button to move on to the next setting.



Screen Saver : If there is no activity the screen saver will be activated after a certain time. You can change the Screen Saver time on this menu.

Photo Slide Show : is used when playing background music while watching picture a slideshows.

Subtitle Color : Change the color and outline of subtitles.

Smart navigation : If there is a VIDEO_TS.IFO file in the folder, clicking on the DVD folder will automatically play back .VOB content.

Set Folder Password : In order to password-protect folders, firstly you will need to setup the Admin Password. Default Admin Password: 0000 (4-zeros). Perform the SETUP-SYSTEM-Load default settings if Admin Password gets lost.



5 Initial Usage

5.1 Movie Playback

When installation is successfully finished, you will able to see Main MENU screen.
You'd better copy a video file into the MOVIE folder in advance.

1 HDTV, MOVIE, MUSIC, PHOTO, SETUP icons are shown.

2 Select the MOVIE menu by using the left/right arrow button on your remote control.



3 After selecting the icon, press the OK( ) button.

4 If you want to change the partition of the HDD, press the Jump/Left button.



5 Using the up/down button, select the Video file content.

By pressing the OK ( )button, you will be able to play the video file.

TIP ~

If you want to play the next video, press the NEXT( ) button.

If you want to play the previous video, press the previous(|◄◄) button.

5.2 Music Playback

You can copy audio files to the MUSIC folder in advance and play music files..

1 If you cannot see the MAIN MENU screen, press the MENU( ) button on your remote control.



2 Select the MUSIC menu( ) on the Main screen and press the OK( ) button.

3 You will see the audio file contents that you have just copied.

4 Select the audio file content using the up/down button. Then by pressing the OK button on the content highlighted you will be able to play back the audio file.

TIP ~

If you want to play the next audio, press the NEXT( ) button.

If you want to play the previous audio, press the previous(|◄◄) button.

5.3 Photo Playback

You may copy image files into the PHOTO folder in advance and play the image or photo files.



1 You can press the PHOTO button on your remote control without selecting from the menu screen

2 Press PHOTO ( ) button.

3 You can see the image files that you just copied.

4 Select the image files using the up/down button. By pressing the OK button, you can easily play the image file content.

5 If you want to play the next image, press the NEXT(>>|) button.

TIP ~
You can play the HDTV, Music and Movie as well as the Photos with the remote control.

If you connect the LAN cable or external USB, Network or USB icon is enabled on the main Menu .
We're supporting up to 4 network PC, 4 USB1 partition , 4 USB2 partition and 4 USB3 partition.



6 Using the remote control

6.1 Descriptions of Each Button

Basically, for playback of multimedia files you choose the file you want by navigating to it with the menu buttons and left/right and up/down arrow buttons and then press the OK button.

6.1.1 Video Playback

When you press the MOVIE button ( ) on your remote control, the TVX-HD MOVIE folder contents are displayed on the TV Screen.

This only applies to the active partition if you have more than one partition.

Press the **JUMP(**)button on your remote control to select another input source.

TVX-HD displays on screen when you press an invalid key.

<NOTE>

▶/II OK	Play or pause file.
■	Stop playing a file.
▶▶I	Go to the next file.
I◀◀	Go to the previous file.
INFO	Shows information of the contents.  Pressing Info button while you are not playing files shows remaining HDD space.
16:9/4:3	4:3 Letter Box / 4:3 Pan & Scan for ordinary TVs / 16:9 for Wide TVs such as HDTV or Plasma TV. If the ratio of the TV is 4:3, select the 4:3 letter box or 4:3 Pan & Scan. If the ratio is 16:9, select 16:9.

① The 4:3 Letter box can show the original ratio of the multimedia file in 16:9.

② The 4:3 Pan & Scan will adjust the image of the 16:9 multimedia file to the 4:3 of the TV screen by scaling the image. (Currently this mode is not supported)

③ 16:9 can adjust any ratio of the multimedia file to the TV screen with the original image.

Pressing the Zoom button while you are playing files, you can change the screen
Vol + : change from 1X to 9X.
CH+/- : change 0% ~ 180%
Left/Right/Up/Down : Scroll the screen.
Zoom and scroll function will be default when you stop the video.



Subtitle color or outline is configurable on the SETUP-MISC menu.
Supports .SUB (bitmap) + .idx subtitle files as well as MKV internal subtitle or smi external subtitle
Some subtitle is not available to change the subtitle position, size or sync.



Select subtitle you want and press right button on your remote control to change the position, size or sync of subtitle.

Change Subtitle Position :

Change Subtitle Size :

Change Subtitle Sync :

You can also change the subtitle sync by using CH +/- button on your remote control.

Pressing GOTO button while you are playing files, You can choose the time. After choosing you can play directly.
The present playing time will be displayed with the GOTO function.

FF/REW Button
Pressing FF button while you are playing files, you can change the FF mode.
2X→4X→ 8X →16X → 32X.

Up/Down Button : 15 seconds skip forward or backward.



15 SEC (Down button) : Back 15 seconds.
15 SEC (Up button) : Skip 15 seconds.

ADD DELETE is used to delete the file or folder from the TVX-HD Local hard disk.
When you do delete files or folders, you must run the HDD check disk periodically.

FUNCTION During playback You can set sleep time by pressing function key repeatedly on a remote control.
SLEEP ON will blink for 3 minutes before turning off.

SETUP In these menus, you can adjust the Contrast, Brightness, Hue and Saturation as well as other setup settings.

BOOKMARK If you stop when playing a movie, the stop position will be automatically saved and you can resume it later anytime by pressing the "bookmark" button on the remote control.
- save up to 32 bookmarks on 32 individual files. (It cannot save 2 bookmarks on a single file.)
- Bookmarking works for all video files.
- A video file where the folder is setup with a password cannot be saved.
- When replaying the same file, only the last play position will be saved (thus, bookmarked).
- A file deleted from the hard disk will be automatically deleted from the bookmark list as well.

Pressing AUDIO button while you are playing multi audio files, you can change to alternate audio tracks.

Adjust the play mode to repeat Track, repeat All or repeat off.

6.1.2 DVD Navigation

For playback of DVD files copied to the HDD, navigate to the **VIDEO_TS.IFO** file and press OK.

Full DVD navigation works as with a standard DVD player.



< DVD Jukebox Keys >

	Play/Pause (when a movie is playing). Select file (in the menu screen).
	Stop playing.
	Go to the next chapter
	Go to the previous chapter
	Show DVD information.
	MENU : Go to the DVD root menu.
	FF/REW Button Up/Down Button : 15 seconds skip or 15 seconds backward.
	AUDIO: Change the audio the available tracks. (International dubbing, Dolby Digital, 2CH, 5.1CH, DTS etc.)

** The operation of “arrow” and “VOLUME UP/DOWN” is the same for Video operation.

6.1.3 Audio Playback

When you press the MUSIC button( ) on your remote control, the contents of the TVX-HD Music folder will be displayed.

It applies only to the active partition(first partition) if you have more than one partition.

TVX-HD displays on screen when you press an invalid key.
If you press audio file, then you will get the screen of music window.
You can choose another song to hear in this music window.

** Some functions may require updating to the latest firmware.
** Press GOTO button when you want to change songs.

< NOTE >

▶/II OK	Play or pause file.
■	Stop playing
▶▶I	Go to the next file.
I◀◀	Go to the previous file.
INFO	Show the information of the audio file. If there is no Tag information, it displays basic file information.
◀ ▶	FF/REW button. CH Up/Down Button : 15 seconds skip or 15 seconds backward.
	Shuffle Function (Random Playback), Press the Shuffle button to play the files of the present directory randomly.
	REPEAT : Adjust the play mode to repeat Track, repeat All or repeat off.

6.1.4 Image Playback

When you press the PHOTO button( ) on the remote control, the contents of the TVX-HD PHOTO folder will be displayed.

It applies only to the active partition(first partition) if you have more than one partition.

TVX-HD displays on screen when you press an invalid key.

< NOTE >

▶/II OK	Play or pause file.
■	Stop playing
▶▶I	Go to the next file.
I◀◀	Go to the previous file.
INFO	Show the information of the image.
◀ ▶	Rotate the image.
ZOOM	You can change and set the size of the picture with the ZOOM. With Zoom mode, you can scroll the image by pressing the arrow buttons.

- You can set the slideshow delay or slide show effect at the SETUP-MISC menu.
- Some non-standard JPEG files may not be displayed..[Progressive jpeg is not supported].
- You can use the Background Music Slide function if there are audio files and image files in same folder.

6.2 Extra Features

6.2.1 Using Cover Art

1 Please change the File list type to Cover Art on the SETUP-SYSTEM.



2 If a name of folder, which on the root folder, is starts with one of below words (case insensitive), it will shows Video cover art mode instead a normal icon mode.

. Folder name : "MOVIE", "movie", "Movie", "VIDEO", "video", "Video"



3 To play a video, press PLAY button.

If file name is Preview_~~, PREVIEW menu iwill be activated.(File name : Preview_aaa.mkv)

4 Press ‘GOTO’ button on the remote controller, you can change the Device.
Press ‘STOP’ button on the remote controller, you can go to up folder.





** **Audio Album Art** : It will show 186*186 Album art for all the folders under "MUSIC", "music", "Music", "AUDIO", "audio", "Audio".



** **Photo Thumbnail mode** : It will show jpeg files as 186*186 thumbnails for all the folders under "PHOTO", "photo", "Photo", "PHoto", "PHOto", "PHOTo".



** If you want add icon image and background image manually, please insert folder.jpg and tvix.jpf file in the folder.

tvix.jpg : 1280*720 resoultion.
Video icon (folder.jpg) : 138*186 resoiution.
Music icon (folder.jpg) : 186*186 resoiution.
Photo icon (folder.jpg) : 186*186 resoiution.

6.2.2 Using the AutoRun Function

When you want to play music with the TVX-HD, but do not have any display devices, the following function may come in handy.

1 Make a folder and name it, “autorun” and place it in the root directory of the First partition.



2 Copy media file(s) or a list file in the “autorun” folder.



3 If you want to change the setup, push the SETUP button on the remote control. Then go to the SETUP-SYSTEM tab. Set AutoRun option to ON. If you set the AutoRun option to OFF, the function will not work. If you select ‘Shuffle,’ files will play randomly.

4 After setting the configuration, turn off the TVX-HD and then turn it on again. The TVX-HD will play the media file from the under ‘/HDD1/autorun’.

6.2.3 Using playlist

TVX-HD allows you to make/edit a playlist without you having to turn on your PC.

1 Move to a folder where you want to create a list, and then press the FUNCTION button.

From the set-up image(as shown below), select the playlist image. ( )



2 Playlist addition is separated into two windows. Select a file that you want to add from the left window, and then click on OK in order to add the file to the list on the right side.

You can move around between the two windows using left/right direction keys.

OK	Left window : make additions to the playlist, Right window: save the playlist file
	Leave the playlist window. If you leave without clicking on OK on the right window, the list does not get saved.
	Remove the selected list from the right window.
CH	Change the order of playback on the right window.

3 Completed list(playlist xx.m3u) is saved where you pressed on FUNCTION, or the place you started to make a playlist.

Since the location is fixed, if you wish to save it in a particular folder, create a folder, and then select the playlist addition button in that particular folder

4 If you want to edit list files, go to list file(playlist xx.m3u), select FUNCTION, and then select the “edit list” icon( ).

** Image file is not available when adding the play list.

** It will not play the file if the location of the saved list file is changed.

6.2.4 Using File Copying

TVX-HD supports File Copy functionality without Using PC.

1. Select the folder containing source files. (Currently, don't support folder copying)
2. Press Function key and select FILE SELECT icon.



3. Select source file by using Up/Down key and OK button.
Do not change to another folder in this mode. If files are selected, selected files are checked.



4. After selecting the file, press the Function key again and then select the COPY icon( ). To cancel copying, press the Function key again and then press cancel icon.
5. In case of paste mode, you can use arrow keys, so that you can change the target folder. Navigate to the folder where you want to copy, and press the Function key again then select the PASTE icon().

6. You will see progress pop up after pressing PASTE icon as shown below



6.2.5 Folder Security

TVX-HD supports folder protection by assigning a password to the folder.



1. Select the folder that you want to password protect.
2. Press the Function button on your remote control.
3. Select the Set Password icon to set up the password.
4. Press a 1~8 digit number from the Numeric key on the remote (Ex: 1234). Press the OK button to complete set up. Perform the SETUP-SYSTEM-Load default settings to clear the password if the Admin Password is lost.



< < Notice >

- The Set password and Remove password icons will be activated when a password is assigned to the folder.


Toggle file list type

Add Playlist

Edit Playlist

Set password

Remove password


File select

File copy

File Paste

File delete


Cancel/Exit

- If you insert a wrong password, TVX-HD automatically goes to the file-selecting page.
- Perform the SETUP-SYSTEM-Load default settings if Admin Password is lost
- The password should consist of numbers only.
- You cannot delete a folder protected by a password with the delete key. Remove the password first.

7 Using Network

7.1 Using UPnP

< When connecting the computer directly to the TVX-HD >



Connect the LAN cable to the LAN port of both the TVX-HD and the PC.

TIPS
In this case, you generally use a LAN cross cable type.
If the computer's LAN card was connected to an Internet line, you can install an additional LAN card to your PC and connect that LAN card to the TVX-HD.

< When connecting with IP Router or Hub >



Connect the LAN cable to the LAN port for an IP Router or Hub.

TIPS
In this case, you generally have to use Direct LAN Cable type.

The UPnP allows you to connect to network easily with uPnP support, and it does not require an IP address. You can immediately playback uPnP connected files (even full HD files) on wired/wireless network environment.

Netshare program allows you can play the TP or DVD jukebox without stutter easily.
We recommend sharing files using the NTFS file system. The FAT32 file system does not contain enough information to create a lasting file name, so TVX-HD doesn't load the file after changing the file name.

7.1.1 How to set up UPnP server to your PC

Although there are various UPnP servers for PC users, We would like to recommend you all to use XBMC UPnP server which is relatively easy to use and supports external subtitles.

1 Download the latest XBMC Media Center for Window from XBMC homepage

at http://xbmc.org/download/

2 Run the XBMC Media center Wizard. When you click 'NEXT', it installs automatically. Then, additional setup is not necessary.

XBMC Media Center Setup
Welcome to the XBMC Media Center Setup Wizard
This wizard will guide you through the installation of XBMC Media Center.
It is recommended that you close all other applications before starting Setup. This will make it possible to update relevant system files without having to reboot your computer.
Click Next to continue.
Next >
Cancel

3 Choose the components you want to install. Press 'NEXT'.


XBMC Media Center Setup
Choose Components
Choose which features of XBMC Media Center you want to install.
Check the components you want to install and uncheck the components you don't want to install. Click Next to continue.
Select the type of install:
Full
Or, select the optional components you wish to install:
XBMC
Language
Skins
Scripts
Plugins
Description
Position your mouse over a component to see its description.
Space required: 135.8MB
Nullsoft Install System v2.44
< Back
Next >
Cancel

4 XBMC Media Center has been installed on your computer..

XBMC Media Center Setup
Completing the XBMC Media Center Setup Wizard
XBMC Media Center has been installed on your computer.
Click Finish to close this wizard.
Run XBMC Media Center
Please visit http://xbmc.org for more information.
< Back
Finish
Cancel

7.1.2 How to set up XBMC server

Once the installation is done, XBMC program will start automatically. If it does not, you are requested to run it by clicking XBMC icon( ).

1. The page is the main. You may change working environment at the Settings as your taste.
   Click SYSTEM - NETWORK.

2. Click ‘Share video and Music…’ and ‘Allow Control of XBMC via UPnP’ option.



3. Click ‘VIDEOS’ on the main screen.



4 Click ‘Add Source’ and ‘BROWSE’. Choose a folder to share and click ‘OK’

5 click ‘SET COTENTS’.

6 Choose you want to use as SCRAPER and click ‘OK’.

7 Click ‘SCAN FOR NEW CONTENT’ on the popup menu to scan contents.



8 Click “MANUAL ADD TO LIBRARY” to add a file manually, and write file name and Genres name..



9 In the same way, you can share the Music’.

◈ Caution while using XBMC

- Some file’s extensions may be shown strangely on TVX-HD.
- Please change TP extension(recorded clip) to TS
- It may take time to read subtitle file(smi, srt, idx+sub) in the beginning of the file play
- If XBMC does not start automatically after re-start, please register XBMC on the START program on your PC.

7.1.3 How to set up Wireless network

You can watch movies without a hard disk with wireless network support. Play videos, music, photos saved in your PC hard disk without having to transfer them to your TVX-HD.
You can play most of the HD video files (up to 18mbps) with 802.11n wireless Wi-Fi dongle (available as an option).

Connect the Wired network, and Upnp list will be displayed automatically.

Have your USB module attached to your TVX-HD, If your PC is connected with wire/ wireless AP router.



1 Press SETUP-NETWORK “Search Wi-Fi Network” for searching your AP or AP router.
2 After the interval of searching, you can see the following popup menu. Select the AP you want to connect with



A Lock icon means the AP uses security option.
WEP key input : WEP 64-Bit/ WEP 128 key and ASCII and HEX key.

WPA key input : ASCII only.
RADIUS (Remote Authentication Dial-In User Services) servers are not supported.
※ You have to configure the WEP setting of the AP using the AP’s instruction in advance.



3 Insert the network key using virtual keyboard.

4 If you insert the correct network key, you should see well-formed TVX-HD Wi-Fi Network Info like following. The network key is Hexadecimal or ASCII.



5 If the network key is wrong or the AP doesn’t work with DHCP setting, you would see some missing fields in TVX-HD Wi-Fi Network Info POP UP. Those fields which you might always see are TVX-HD IP and DNS.
6 If you still have problems after entering the correct key, please recheck your AP settings or reconnect the USB port.

7 Network disk setting **:** This setting is same as the wired network setting.
8 If Wifi network doesn’t work, press SETUP-NETWORK- “Wi-Fi IP setting” and select DHCP or static IP again.

※ Caution ※

1. In connecting the Wireless USB to TVX-HD Device. The TVX-HD needs to be powered off initially and then Powered ON .Then on the Network setting Menu WIFI IP setting will be enabled.
2. For better Wi-Fi signals adjust the position of AP and USB module
3. If you play high definition files over Wi-Fi, you will see stuttering sometimes. Also, depending on the environment, you may experience stuttering when you play HD files.
4. If you use a USB Wi-Fi adapter with another USB device, it may not work properly.

*** After changing an AP setting, you must search the wireless network as in Step 2.**

7.1.4 How to use UPnP

1. Select 'VIDEO' mode on the main at the main page

2. Press 'Left' button and then 'Right' button of the remote, then it moves to (

) device. To see UPnP device, press 'OK' button on the remote.



3. If you select one of them, you can see the contents that you set up on XBMC server. If you select 'Video Library', you can see medial files that are in the PC or network device.

4. If you select a file that you want to play, it will be played like you do with the HDD.

** Some file's extensions may be shown strangely or not shown by network servers.

7.2 Using NetShare

7.2.1 NetShare Installation

Netshare program allows you can play the TP or DVD jukebox without stutter easily.
We recommend sharing files using the NTFS file system. The FAT32 file system does not contain enough information to create a lasting file name, so TVX-HD doesn't load the file after changing the file name.

1. Most likely there will be an updated NetShare version on our web site.
You may download and install using the latest TVX-HD Netshare installer or install TVX-HD Netshare from the enclosed CD.

2. Run Netshare installer and follow the on-screen prompts to install software.

3. The “Choose Destination Location” window will appear. Click on “Next” if you want to install the Net Share in the default directory. Otherwise, you can choose a different directory by clicking on “Browse”.


TViX NetShare Setup
Choose Destination Location
Select folder where setup will install files.
Setup will install TVX NetShare in the following folder.
To install to this folder, click Next. To install to a different folder, click Browse and select another folder.
Destination Folder
E:\Program Files\DVICO\TVXNetShare
Browse...
InstallShield
Next >
Cancel

4. Please select the location where you would like to share the folder. You may click the browser to find a shared folder.



We recommend sharing files using the NTFS file system.

5 The “Setup status” window will appear.



6 Press YES button if you want to run the Net Share automatically.



7 By clicking the Finish button, the software installation is done.



8 Press **"Unblock"** for the Windows Security Alert.

Windows Security Alert
To help protect your computer, Windows Firewall has blocked some features of this program.
Do you want to keep blocking this program?
Name: TViXNetShare
Publisher: DVICO
Keep Blocking
Unblock
Ask Me Later
Windows Firewall has blocked this program from accepting connections from the Internet or a network. If you recognize the program or trust the publisher, you can unblock it. When should I unblock a program?

7.2.2 Using NetShare

1 Click Start, point to Program->DVICO->NetShare.
If Netshare is already running, you don't need to run this program again.



2 After starting the Net Share program, you can see the NetShare icon in the tray..





3 Start the setting by right clicking the NetShare tray icon at the lower-righthand corner of the screen.





- Start Sharing : Used to start the sharing
- Stop Sharing : Used to stop the sharing
- Settings : Used to set the share folder
- Exit

4 After running the NetShare software application on the system, right click on the NetShare icon and select Settings.

- NetShare AutoRun : used to autorun when Windows re-starts.
- Auto Sharing at Program Run : used to start sharing automatically at program startup.
- Folder to Share : used to Select the folder and Files from the drives shared by Clicking on the Browse icon.

In case of FAT32 file system, TVX-HD doesn't load the file after changing the file name.

7.2.3 Sharing of Multi folders

1 After running the Netshare software Application, right click on the Netshare ICON.





2 Click on Browse, Corresponding to Folder 1 to Share.
3 Select the Appropriate folder, Containing Media Files from desired Drive and Click OK.

4 Again Click on Browse, Corresponding to Folder 2~ Folder4 to Share.
5 Select the Appropriate folder, Containing Media Files from the desired drive and Click OK.



CAUTION
If you press the stop sharing when the network is connected, you can see “TVX-HD Sharing closed.” On the setting feature.
You must again Press the “start sharing” on the tray window for network Sharing to start.

7.3 Using SAMBA Client

7.3.1 Set Network Configurations Under Windows XP (SAMBA mode)



1 Select the folder you want to share. Right-click that folder and click 'Sharing and Security' in the popup menu.


tvixhd1 Properties
General Sharing Security Customize
You can share this folder with other users on your network. To enable sharing for this folder, click Share this folder.
Do not share this folder
Share this folder
Share name: tvixhd1
Comment:
User limit: Maximum allowed
Allow this number of users:
To set permissions for users who access this folder over the network, click Permissions.
Permissions
To configure settings for offline access, click Caching.
Caching
Windows Firewall will be configured to allow this folder to be shared with other computers on the network.
View your Windows Firewall settings
OK
Cancel
Apply

2 Check 'Share this folder' on the network and type in the share name 'tvixhd1 (this is the only available one at the moment)'.

3 Use 'Everyone' if 'Everyone' is displayed, otherwise you don't have to change anything. Also, add 'Everyone' to the security tab.



4 After that, the shared folder will be displayed like the following picture.

5 Move to 'Settings' > 'Control Panel' > 'Administrative Tools' > 'Computer Management' > 'Local Users and Groups' > 'Users', and double click ‘Guest’.



CAUTION
This is for Windows XP Professional. Windows XP Home users cannot see this window. If you cannot find ‘Administrative Tools’ in the Control Panel, click “Switch to classic view” in the upper-left corner of the screen.

6 Uncheck ‘Account is disabled’



7 'GUEST' must be shown as the following image (a red X mark should not be shown on 'Guest').



8 Move to 'Control Panel' > 'Network connections', and select 'Properties' s by right click on the mouse.



9 Remove "Guest" from the 'User Rights Assignment' > 'Deny access to this computer from the network' option.



10) Move to ‘Access this computer from the network’, and then select ‘Properties’ by right clicking the mouse or double clicking it.





11) Click on ‘Add User or Group’



12) Type in “Guest” and then click on “OK” button.

13) Press OK, and Guest will be registered.

< When connecting Computer to TVX-HD directly >
In this case, you have to use Cross LAN cable type generally.
If the computer's LAN card was connected to Internet line, you can mount additional LAN card to your PC and connect that additional LAN card to TVX-HD.

1 Move to 'Control Panel' > 'Network connections', and select 'Properties' by right click on the mouse.


LAN or High-Speed Internet
Local Area Connection
LAN or High-Speed Inter...
Connected
Local Area Connection 3
Local Area Connection 3 Properties
General
Authentication
Advanced
Windows Firewall
Protect my computer and network by limiting or preventing access to this computer from the Internet
Settings...
Internet Connection Sharing
Allow other network users to connect through this computer's Internet connection
Allow other network users to control or disable the shared Internet connection
Learn more about Internet Connection Sharing.
Settings...

2 When Windows 2000 or XP, Check "Allow other network users to connect through this computer's internet connection"

3 Double click 'TCP/IP->LAN card' that you want to use on your computer. You must select the additional LAN card.
Check 'Specify an IP address', and write 'IP address' & 'Subnet mask' that you want to use.
Ex) IP address : 192.168.0.1 Subnet mask : 255.255.255.0


Internet Protocol (TCP/IP) Properties
General
You can get IP settings assigned automatically if your network supports this capability. Otherwise, you need to ask your network administrator for the appropriate IP settings.
Obtain an IP address automatically
Use the following IP address:
IP address: 192 . 168 . 0 . 1
Subnet mask: 255 . 255 . 255 . 0
Default gateway:
Obtain DNS server address automatically
Use the following DNS server addresses:
Preferred DNS server:
Alternate DNS server:
Advanced...
OK
Cancel

< When connecting with IP Router or Hub >

If you have already been assigned dynamic IP address from a DHCP Server or IP Router in your local area network, then no need to write a static IP address. Then obtain the automatically assigned IP address or write an IP address & Subnet mask that the DHCP Server or the IP Router provides.
Select 'Control Panel' > 'Network Connections', and select 'Status' properties by right clicking the mouse.
After clicking the Support tab, you should see an IP Address. (ex: 192.168.1.127)



< Disable Windows Firewall >

1. Move to 'Control Panel' > 'Network Connections', and select 'Properties' by right clicking on the mouse. Click on the 'Advanced' tab. Disable 'Internet Connection Firewall'.
2. If you use service pack 2, click on 'Settings' at 'Windows Firewall'.
3. Check 'Off' and then click 'OK'


Local Area Connection Properties
General Authentication Advanced
Windows Firewall
Protect my computer and network by limiting or preventing access to this computer from the Internet
Settings...
OK
Cancel


Windows Firewall
General Exceptions Advanced
Windows Firewall is helping to protect your PC
Windows Firewall helps protect your computer by preventing unauthorized users from gaining access to your computer through the Internet or a network.
On (recommended)
This setting blocks all outside sources from connecting to this computer, with the exception of those selected on the Exceptions tab.
Don't allow exceptions
Select this when you connect to public networks in less secure locations, such as airports. You will not be notified when Windows Firewall blocks programs. Selections on the Exceptions tab will be ignored.
Off (not recommended)
Avoid using this setting. Turning off Windows Firewall may make this computer more vulnerable to viruses and intruders.
Windows Firewall is using your non-domain settings.
What else should I know about Windows Firewall?
OK
Cancel

7.3.2 Setting Static IP Network Configurations in TVX-HD

1 Press [SETUP] button on the remote. setup screen will be displayed. On that Set UP screen, select Network setting→Network disk and type the IP address in the Server IP. (ex: 172.28.1.70)
The default is DHCP and if you want to set Static IP, you can select and change Static IP on the IP setting.
If you have used the DHCP you don't need to assign the IP address because it will be assigned automatically.

2 If you cannot access via LAN with DHCP setting, we recommend to use the Static IP setting.




Static IP Setting
IP ADRESS 000 000 000 000
SUBNET MASK 000 000 000 000
GATEWAY 000 000 000 000
DNS SERVER 000 000 000 000
OK
CANCEL

3 Select 'Control Panel > 'Network Connections', and select 'Status' properties by right clicking the mouse. After clicking the Support tab, press details, and you can see the Network connection details.
Copy the Subnet Mask, default gateway, and DNS server addresses from the PC listing.
You must write a different IP address (ex: 172.28.1.**70** → 172.28.1.**168**) wherethe first three numbers in the TVX-HD's IP address are the same as the PC's and the fourth number is different.




Static IP Setting
IP ADRESS 172 000 000 001
SUBNET MASK 255 255 255 000
GATEWAY 172 000 000 001
DNS SERVER 172 028 000 001
OK
CANCEL

4 When the setting is successfully finished, you will be able to see the 4 PC Tray Icons. Network Disk is supported up to 4 PC Tray system. You can see the partition on the network icon like below image.

5 You may check for detailed usage at the TVX-HD website.

8 Firmware Upgrade

1. Download the latest firmware and unzip it, and move to your external HDD or USB memory stick.

2. Connect the TVX-HD to your TV

3. Select the unzipped firmware (Ex: tvixfw_1.0.0.fwp) and press OK on the remote to start upgrading.

4. New firmware upgrade is in progress. When the upgrade is successfully finished, the TVX-HD will reboot automatically.
After the upgrade, all settings will be initialized.



5. If power is off accidentally while upgrading firmware, the safe-mode upgrade is necessary to finish the upgrade. Press the 'POWER' button on the top panel for 5 seconds and safe-mode upgrade screen will be displayed.

6. You can upgrade a new firmware through internet that is connected with your TVX-HD.
   - Public version: Press **Automatic F/W Update** on the setup-system and then select an F/W to upgrade.
   - Beta version, please press 2,3,8,2 of the numeric keys and then press the 'Function' on the on the setup-system, and then select the F/W to upgrade.

9 Using USB Connection with a PC

9.1 Making a Partition and Formatting the HDDs

1 Under Windows 2000 or above OS, you can make a partition and format the HDD using the Disk Manager utility.

2 Right click “My Computer” → Choose “manage” from the pop up menu and the “Computer Management” window will appear → choose “Disk Management” folder.

3 The disk list will appear on the right side of the “Computer Management” windows. Right click the TVX-HDD from the list, and from the pop up menu choose “make partition” to create partitions on the chosen disk.



4 When the New Partition Wizard appears, press “Next>”.


New Partition Wizard
Welcome to the New Partition Wizard
This wizard helps you create a partition on a basic disk.
A basic disk is a physical disk that contains primary partitions, extended partitions, and logical drives. You can use any version of Windows or MS-DOS to gain access to partitions on basic disks.
To continue, click Next.
< Back
Next >
Cancel

5 Choose the partition type and format the HDD. If you want several partitions, select Extended Partition.


New Partition Wizard
Select Partition Type
There are three types of partitions: primary, extended, and logical.
Select the partition you want to create:
Primary partition
Extended partition
Logical drive
Description
A primary partition is a volume you create using free space on a basic disk. Windows and other operating systems can start from a primary partition. You can create up to four primary partitions or three primary partitions and an extended partition.
< Back
Next >
Cancel

6 Select the partition size. If you want one partition, press “Next>”. For FAT32, size is limited to 32000MB or under.


New Partition Wizard
Specify Partition Size
Choose a partition size that is between the maximum and minimum sizes.
Maxium disk space in megabytes (MB): 19571
Minimum disk space in MB: 8
Partition size in MB: 19571
< Back
Next >
Cancel

7 Select the Drive Letter. Then press the “Next>” button.


New Partition Wizard
Assign Drive Letter or Path
For easier access, you can assign a drive letter or drive path to your partition.
Assign the following drive letter: J
Mount in the following empty NTFS folder:
Browse...
Do not assign a drive letter or drive path
< Back
Next >
Cancel

8 Select the partition Format. If you choose FAT32 file format on Windows 2000/XP, the drives maximum

size will be limited to 32GBs. If you want to use a single drive letter of 32GBs or more, you have to format on Windows 98SE/ME. We don't recommend the FAT32 partition to record the DTV channel.


New Partition Wizard
Format Partition
To store data on this partition, you must format it first.
Choose whether you want to format this partition, and if so, what settings you want to use.
Do not format this partition
Format this partition with the following settings:
File system:
NTFS
Allocation unit size:
Default
Volume label:
New Volume
Perform a quick format
Enable file and folder compression
< Back
Next >
Cancel

9 When completed, detailed information will appear as shown below. Click the "OK" button to finish.



9.2 Unplug or Eject Hardware

1 On the windows tray, double click the hot swap icon. The “Unplug or Eject Hardware” window will appear. Press the Stop button if you want to unplug the device.


Unplug or Eject Hardware
Select the device you want to unplug or eject, and then click Stop. When Windows notifies you that it is safe to do so unplug the device from your computer.
Hardware devices:
USB Mass Storage Device
USB Mass Storage Device
Properties
Stop
Display device components
Show Unplug/Eject icon on the taskbar
Close

2 Press OK on “Stop a Hardware device” window.

Stop a Hardware device
Confirm devices to be stopped, Choose OK to continue.
Windows will attempt to stop the following devices. After the devices are stopped they may be removed safely.
USB Mass Storage Device
Maxtor 52049H4 USB Device
OK
Cancel

3 Press OK and unplug the device.



Close folder or disk on My computer before unplugging the Hard disk.

If folder is open, unplugging it may not work properly.

10 Troubleshooting

**** For detailed instructions, please refer to the latest pdf file on the TVX-HD Homepage or TVX-HD FAQ.**

Under no circumstances should you try to repair the system yourself, as this will invalidate the warranty. Do not open the system as there is a risk of electric shock. If a fault occurs, first check the points listed below before taking the system for repair.

No Screen Display. Video Output not working.	1. Press the TVOUT button on TVX-HD remote to toggle between TV OUT settings. 2. Check the TV-OUT settings and cable-type on the TVX-HD and ensure that it is consistent with the VIDEO-IN settings of the TV. 3. Ensure that the Video Cable is securely connected to the TVX-HD and to the TV.
The TVX-HD does not respond to the Remote Control. Menu Items cannot be selected.	1. Reduce the distance between the Remote and the TVX-HD and try again. 2. Replace remote batteries. 3. Perform a Hardware factory Reset Procedure. 4. Check for interference from other IR sources by trying to operate the TVX-HD with all other components turned off.
TVX-HD does not show subtitle.	Re-name the subtitle file the same as avi file name (except for file type extensions). TVX-HD can show the subtitle when the file name is same.
TVX-HD does not display the Network-shared Folder on your PC.	1. Check network connection between your PC and the TVX-HD. 2. Reboot the TVX-HD and re-establish the connection. 3.Depending on network environment, there may be a delay in searching for the network for up to about 10 minutes. 4. Ensure that WEP and SSID settings are accurate.
Unable to Play Xvid, or MPEG, or AVI video files etc.	1. Ensure that the selected video file contains supported video codec. 2. Run the check Disk on the SETUP. 3. If playing a file from a network drive, there may be too much traffic on the network (check for virus). Try to reboot your PC and establish connection again.

11 Appendix - Technical Terms

HDMI

The High-Definition Multimedia Interface (HDMI) is an all-digital audio/video interface capable of transmitting uncompressed streams. HDMI is compatible with High-bandwidth Digital Content Protection (HDCP) Digital Rights Management technology.
HDMI provides an interface between any compatible digital audio/video source, such as a set-top box, a DVD player, a PC, a video game console, or an AV receiver and a compatible digital audio and/or video monitor, such as a digital television (DTV). In 2006, HDMI began to appear as a feature on prosumer, HDTV camcorders and even high-end digital still cameras.

DivX

DivX is the name of a revolutionary new video codec which is based on the new MPEG-4 compression standard for video. When you install a video codec on your system it basically works as an add-on to your system with instructions on how to compress/decompress video in that video format. Once you've installed the DivX codec on your system you will be able to play DivX movies using Windows Media Player or any other DivX-enabled player.
Despite the fact that DivX movies offer better compression and higher quality video than regular MPEG movies it takes more time to encode due to the incredible compression technology. The DivX codec makes it possible to compress/encode a full-length movie at near DVD-quality, which is small enough to fit on a single CD (700MB). The DivX video is usually combined with MP3 audio to produce both high quality video and audio.

Xvid

XviD is the name of a new open-source video codec, which like the DivX is based on the new MPEG-4 compression standard for video. It's currently being developed by people from all over the world. When you install a video codec on your system, it basically works as an ‘add-on’ to your system with instructions on how to compress/decompress video in that video format. Once you've installed the XviD codec on your system you will be able to play XviD movies using Windows Media Player or any other XviD-enabled player.

MPEG

MPEG stands for Motion Picture Experts Group. This is the same group that made the MPEG-1 (used in VideoCDs), MPEG-2 (used in DVD and SuperVCDs and other high bandwidth systems) and MPEG-4 (ASF, DivX, WMV, low-mid bandwidth systems) standards. They are also responsible for MP3 (MPEG Audio Layer 3) and AAC audio compression standards.

VOB

VOB stands for Video Objects. DVD movies are stored in VOB files. Each VOB file has a number of video/audio/subpicture streams.

AVI

AVI stands for Audio Video Interleave. AVI is a file format, like MP3 or JPG. But unlike these formats, AVI is a container format, meaning it can contain video/audio compressed files using many different combinations of codecs. Therefore, while MP3 and JPG can only contain a certain kind of compression (MPEG Audio Layer 3 and JPEG), AVI can contain many different kinds of compression (eg. DivX video + WMA audio or Indeo video + PCM audio) as long as a codec is available for encoding/decoding. All AVI files look the same on the "outside", but on the "inside", they may be completely different. Almost all tools on this site are not just DivX tools, but also AVI tools, so will work with many other codecs.

Dolby Digital

Initially known as Audio Coding 3, Dolby Digital is a synonym for Dolby Digital these days. Dolby Digital is an advanced audio compression technology allowing to encode up to 6 separate channels at bit-rates up to 640kbit/s. For more information please check out the Dolby website.

DTS

By supplying film studios with outstanding techniques for delivering soundtracks to an attentive audience, DTS digital sound is now featured on virtually 100% of major Hollywood releases. Although the technology used for motion pictures differs from that featured in consumer and professional audio music and home theater systems, their DTS heritage means end users can enjoy sound that closely matches the original.

WMA

WMA stands for Windows Media Audio. It is a proprietary format developed by Microsoft for audio streaming and compression. WMA files, theoretically, has double the compression rate of MP3s, although this is debatable.

Ogg Vorbis

Ogg Vorbis is a new audio compression format. It is roughly comparable to other formats used to store and play digital music, such as MP3, VQF, AAC, and other digital audio formats. It is different from these other formats because it is completely free, open, and unpatented.
Ogg Vorbis has been designed to completely replace all proprietary, patented audio formats. That means that you can encode all your music or audio content in Vorbis and never look back.

480P

---

480 progressive; form of standard-definition digital television (SDTV) comparable to VGA computer displays but not considered high-definition television (HDTV), though 480p is discernibly cleaner and slightly sharper than analog television. The native resolution of DVD is 480p, but that resolution can be seen only if a DVD player outputs a progressive-scan signal and the DTV has progressive-scan or component-video inputs; it is also known as EDTV.

720P

---

720 progressive. One of two currently used formats designated as high-definition television in the ATSC DTV standard, this technology comprises 720 vertical pixels and 1,280 horizontal pixels. The p stands for progressive, as opposed to interlaced, scanning, which is used in the other accepted HDTV standard, known as 1080i. Contrary to myth, 720p is not inferior to 1080i; 720p has fewer lines but also has the advantages of progressive scanning and a constant vertical resolution of 720 lines, making it better able to handle motion.

1080i

1080 interlaced; one of two formats designated as high-definition television in the ATSC DTV standard, with 1,080 vertical pixels by 1,920 horizontal pixels. The i stands for interlaced, as opposed to progressive scanning, used in the second HDTV standard, 720p. Contrary to myth, 1080i is not superior to 720p; 1080i has more scanning lines but also suffers the disadvantages of interlaced scanning.

NTSC

The NTSC (National Television Standards Committee) was responsible for developing, in 1953, a set of standard protocol for television (TV) broadcast transmission and reception in the United States. Two other standards - Phase Alternation Line (PAL) and Sequential Couleur avec Memoire (SECAM) - are used in other parts of the world. The NTSC standards have not changed significantly since their inception, except for the addition of new parameters for color signals. NTSC signals are not directly compatible with computer systems. An NTSC TV image has 525 horizontal lines per frame (complete screen image). These lines are scanned from left to right and from top to bottom. Every other line is skipped. Thus it takes two screen scans to complete a frame: one scan for the odd-numbered horizontal lines, and another scan for the even-numbered lines. Each half-frame screen scan takes approximately 1/60 of a second; a complete frame is scanned every 1/30 second. This alternate-line scanning system is known as interlacing.

PAL

Phase Alternation Line (PAL) is the analog television display standard that is used in Europe and certain other parts of the world. PAL is one of the three major TV standards together with the American National Television Systems Committee(NTSC) color television system and the French Sequential Couleur avec Memoire (SECAM). NTSC is also used in Japan. SECAM is used in countries of the former Soviet Union.
Like SECAM, PAL scans the cathode ray tube (CRT) horizontally 625 times to form the video image. NTSC scans 525 lines. Color definitions between the systems vary slightly.

12 GNU General Public License

DVICO Co., Ltd is using a part of Free Software code under the GNU General Public License in operating player. This General Public License applies to most of the Free Software Foundation's code and to any other program whose authors commit by using it. The Free Software is copyrighted by Free Software Foundation, Inc. and the program is licensed "As is" without warranty of any kind. Users are free to download the base source code of the dvico TVX-HD players at the following Address: www.TViX.co.kr/gpl The source code can be sent to your address via airmail for a charge of actual expense executed. Please contact us at sales@dvico.com

GNU GENERAL PUBLIC LICENSE
Version 2, June 1991
Copyright (C) 1989, 1991 Free Software Foundation, Inc.
51 Franklin Street, Fifth Floor, Boston, MA 02110-1301, USA

Everyone is permitted to copy and distribute verbatim copies
of this license document, but changing it is not allowed.

Preamble

The licenses for most software are designed to take away your freedom to share and change it. By contrast, the GNU General Public License is intended to guarantee your freedom to share and change free software--to make sure the software is free for all its users. This General Public License applies to most of the Free Software Foundation's software and to any other program whose authors commit to using it. (Some other Free Software Foundation software is covered by the GNU Lesser General Public License instead.) You can apply it to your programs, too.

When we speak of free software, we are referring to freedom, not price. Our General Public Licenses are designed to make sure that you have the freedom to distribute copies of free software (and charge for this service if you wish), that you receive source code or can get it if you want it, that you can change the software or use pieces of it in new free programs; and that you know you can do these things.

To protect your rights, we need to make restrictions that forbid anyone to deny you these rights or to ask you to surrender the rights. These restrictions translate to certain responsibilities for you if you distribute copies of the software, or if you modify it.

For example, if you distribute copies of such a program, whether gratis or for a fee, you must give the recipients all the rights that you have. You must make sure that they, too, receive or can get the source code. And you must show them these terms so they know their rights.

We protect your rights with two steps: (1) copyright the software, and (2) offer you this license which gives you legal permission to copy, distribute and/or modify the software.

Also, for each author's protection and ours, we want to make certain that everyone understands that there is no warranty for this free software. If the software is modified by someone else and passed on, we want its recipients to know that what they have is not the original, so that any problems introduced by others will not reflect on the original authors' reputations.

Finally, any free program is threatened constantly by software patents. We wish to avoid the danger that redistributors of a free program will individually obtain patent licenses, in effect making the program proprietary. To prevent this, we have made it clear that any patent must be licensed for everyone's free use or not licensed at all.

The precise terms and conditions for copying, distribution and modification follow.

TERMS AND CONDITIONS FOR COPYING, DISTRIBUTION AND MODIFICATION

0. This License applies to any program or other work which contains a notice placed by the copyright holder saying it may be distributed under the terms of this General Public License. The "Program", below, refers to any such program or work, and a "work based on the Program" means either the Program or any derivative work under copyright law: that is to say, a work containing the Program or a portion of it, either verbatim or with modifications and/or translated into another language. (Hereinafter, translation is included without limitation in the term "modification".) Each licensee is addressed as "you".

Activities other than copying, distribution and modification are not covered by this License; they are outside its scope. The act of running the Program is not restricted, and the output from the Program is covered only if its contents constitute a work based on the Program (independent of having been made by running the Program). Whether that is true depends on what the Program does.

1. You may copy and distribute verbatim copies of the Program's source code as you receive it, in any medium, provided that you conspicuously and appropriately publish on each copy an appropriate copyright notice and disclaimer of warranty; keep intact all the notices that refer to this License and to the absence of any warranty; and give any other recipients of the Program a copy of this License along with the Program.

You may charge a fee for the physical act of transferring a copy, and you may at your option offer warranty

protection in exchange for a fee.
2. You may modify your copy or copies of the Program or any portion of it, thus forming a work based on the Program, and copy and distribute such modifications or work under the terms of Section 1 above, provided that you also meet all of these conditions:
a) You must cause the modified files to carry prominent notices stating that you changed the files and the date of any change.
b) You must cause any work that you distribute or publish, that in whole or in part contains or is derived from the Program or any part thereof, to be licensed as a whole at no charge to all third parties under the terms of this License.
c) If the modified program normally reads commands interactively when run, you must cause it, when started running for such interactive use in the most ordinary way, to print or display an announcement including an appropriate copyright notice and a notice that there is no warranty (or else, saying that you provide a warranty) and that users may redistribute the program under these conditions, and telling the user how to view a copy of this License. (Exception: if the Program itself is interactive but does not normally print such an announcement, your work based on the Program is not required to print an announcement.)
These requirements apply to the modified work as a whole. If identifiable sections of that work are not derived from the Program, and can be reasonably considered independent and separate works in themselves, then this License, and its terms, do not apply to those sections when you distribute them as separate works. But when you distribute the same sections as part of a whole which is a work based on the Program, the distribution of the whole must be on the terms of this License, whose permissions for other licensees extend to the entire whole, and thus to each and every part regardless of who wrote it.
Thus, it is not the intent of this section to claim rights or contest your rights to work written entirely by you; rather, the intent is to exercise the right to control the distribution of derivative or collective works based on the Program.
In addition, mere aggregation of another work not based on the Program with the Program (or with a work based on the Program) on a volume of a storage or distribution medium does not bring the other work under the scope of this License.
3. You may copy and distribute the Program (or a work based on it, under Section 2) in object code or executable form under the terms of Sections 1 and 2 above provided that you also do one of the following:
a) Accompany it with the complete corresponding machine-readable source code, which must be distributed under the terms of Sections 1 and 2 above on a medium customarily used for software interchange; or,
b) Accompany it with a written offer, valid for at least three years, to give any third party, for a charge no more than your cost of physically performing source distribution, a complete machine-readable copy of the corresponding source code, to be distributed under the terms of Sections 1 and 2 above on a medium customarily used for software interchange; or,
c) Accompany it with the information you received as to the offer to distribute corresponding source code. (This alternative is allowed only for noncommercial distribution and only if you received the program in object code or executable form with such an offer, in accord with Subsection b above.)
The source code for a work means the preferred form of the work for making modifications to it. For an executable work, complete source code means all the source code for all modules it contains, plus any associated interface definition files, plus the scripts used to control compilation and installation of the executable. However, as a special exception, the source code distributed need not include anything that is normally distributed (in either source or binary form) with the major components (compiler, kernel, and so on) of the operating system on which the executable runs, unless that component itself accompanies the executable.
If distribution of executable or object code is made by offering access to copy from a designated place, then offering equivalent access to copy the source code from the same place counts as distribution of the source code, even though third parties are not compelled to copy the source along with the object code.
4. You may not copy, modify, sublicense, or distribute the Program except as expressly provided under this License. Any attempt otherwise to copy, modify, sublicense or distribute the Program is void, and will automatically terminate your rights under this License. However, parties who have received copies, or rights, from you under this License will not have their licenses terminated so long as such parties remain in full compliance.
5. You are not required to accept this License, since you have not signed it. However, nothing else grants you permission to modify or distribute the Program or its derivative works. These actions are prohibited by law if you do not accept this License. Therefore, by modifying or distributing the Program (or any work based on the Program), you indicate your acceptance of this License to do so, and all its terms and conditions for copying, distributing or modifying the Program or works based on it.
6. Each time you redistribute the Program (or any work based on the Program), the recipient automatically receives a license from the original licensor to copy, distribute or modify the Program subject to these terms and conditions. You may not impose any further restrictions on the recipients' exercise of the rights granted herein. You are not responsible for enforcing compliance by third parties to this License.

7. If, as a consequence of a court judgment or allegation of patent infringement or for any other reason (not limited to patent issues), conditions are imposed on you (whether by court order, agreement or otherwise) that contradict the conditions of this License, they do not excuse you from the conditions of this License. If you cannot distribute so as to satisfy simultaneously your obligations under this License and any other pertinent obligations, then as a consequence you may not distribute the Program at all. For example, if a patent license would not permit royalty-free redistribution of the Program by all those who receive copies directly or indirectly through you, then the only way you could satisfy both it and this License would be to refrain entirely from distribution of the Program.
If any portion of this section is held invalid or unenforceable under any particular circumstance, the balance of the section is intended to apply and the section as a whole is intended to apply in other circumstances.
It is not the purpose of this section to induce you to infringe any patents or other property right claims or to contest validity of any such claims; this section has the sole purpose of protecting the integrity of the free software distribution system, which is implemented by public license practices. Many people have made generous contributions to the wide range of software distributed through that system in reliance on consistent application of that system; it is up to the author/donor to decide if he or she is willing to distribute software through any other system and a licensee cannot impose that choice.
This section is intended to make thoroughly clear what is believed to be a consequence of the rest of this License.
8. If the distribution and/or use of the Program is restricted in certain countries either by patents or by copyrighted interfaces, the original copyright holder who places the Program under this License may add an explicit geographical distribution limitation excluding those countries, so that distribution is permitted only in or among countries not thus excluded. In such case, this License incorporates the limitation as if written in the body of this License.
9. The Free Software Foundation may publish revised and/or new versions of the General Public License from time to time. Such new versions will be similar in spirit to the present version, but may differ in detail to address new problems or concerns.
Each version is given a distinguishing version number. If the Program specifies a version number of this License which applies to it and "any later version", you have the option of following the terms and conditions either of that version or of any later version published by the Free Software Foundation. If the Program does not specify a version number of this License, you may choose any version ever published by the Free Software Foundation.
10. If you wish to incorporate parts of the Program into other free programs whose distribution conditions are different, write to the author to ask for permission. For software which is copyrighted by the Free Software Foundation, write to the Free Software Foundation; we sometimes make exceptions for this. Our decision will be guided by the two goals of preserving the free status of all derivatives of our free software and of promoting the sharing and reuse of software generally.
NO WARRANTY
11. BECAUSE THE PROGRAM IS LICENSED FREE OF CHARGE, THERE IS NO WARRANTY FOR THE PROGRAM, TO THE EXTENT PERMITTED BY APPLICABLE LAW. EXCEPT WHEN OTHERWISE STATED IN WRITING THE COPYRIGHT HOLDERS AND/OR OTHER PARTIES PROVIDE THE PROGRAM "AS IS" WITHOUT WARRANTY OF ANY KIND, EITHER EXPRESSED OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. THE ENTIRE RISK AS TO THE QUALITY AND PERFORMANCE OF THE PROGRAM IS WITH YOU. SHOULD THE PROGRAM PROVE DEFECTIVE, YOU ASSUME THE COST OF ALL NECESSARY SERVICING, REPAIR OR CORRECTION.
12. IN NO EVENT UNLESS REQUIRED BY APPLICABLE LAW OR AGREED TO IN WRITING WILL ANY COPYRIGHT HOLDER, OR ANY OTHER PARTY WHO MAY MODIFY AND/OR REDISTRIBUTE THE PROGRAM AS PERMITTED ABOVE, BE LIABLE TO YOU FOR DAMAGES, INCLUDING ANY GENERAL, SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES ARISING OUT OF THE USE OR INABILITY TO USE THE PROGRAM (INCLUDING BUT NOT LIMITED TO LOSS OF DATA OR DATA BEING RENDERED INACCURATE OR LOSSES SUSTAINED BY YOU OR THIRD PARTIES OR A FAILURE OF THE PROGRAM TO OPERATE WITH ANY OTHER PROGRAMS), EVEN IF SUCH HOLDER OR OTHER PARTY HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.